



1.) CUT PIPE TO SIZE OF THE TEE



2.) GLUE TEE INTO PIPE**



3.) CONNECT COPPER WIRE TO EXISITING PUMP GROUND USING SPLIT CONNECTOR

PH: 561-455-0252 FAX: 561-455-0257 EMAIL: SUPPORT@SOLAXX.COM
** Glue Not Included



1.) CUT PIPE TO SIZE OF THE TEE



2.) GLUE TEE INTO PIPE**



3.) CONNECT COPPER WIRE TO EXISITING PUMP GROUND USING SPLIT CONNECTOR

PH: 561-455-0252 FAX: 561-455-0257 EMAIL: SUPPORT@SOLAXX.COM
** Glue Not Included